

## LONG TERM RADON TEST KIT INSTRUCTIONS

### DO NOT OPEN PLASTIC BAG UNTIL READY TO TEST


**Important:** **Test must run for a minimum of 3 months/maximum one full year.** Record stop date on calendar as a reminder of when to stop and return the test kit to lab for analysis. **Do not disturb the test kit during the measurement period.**

1. Select the room in which you want to place test kit for entire year. This room should be the lowest livable area of the home. The basement is appropriate if a bedroom, family room, or similar area is located there.
2. When you are ready to begin testing, open the plastic bag. Remove the test kit from the bag. (The test kit is the small black round disk which contains bar code)
3. Place the test kit on a flat surface or suspend it using the clip provided at least 20 inches above the floor and at least 4 inches from any other object. Keep the detector 3 feet from any window, exterior door, or other openings and at least 1 foot from any exterior wall.
4. Record your name, address, phone number, sample kit bar code number, test start date, and test location on the front of this information card. Do not record your stop date until you are ready to mail the test kit.

### IMPORTANT - DO NOT PLACE THIS TEST KIT:

- Near heat or air conditioning registers, or other places where it will be subjected to constantly moving air;
  - Where it will get wet or in places of high humidity (i.e. kitchen, bathroom, or laundry room);
  - In direct sunlight or near heat sources.
5. **Stop the test after a maximum of one full year as follows:**
- Record stop date on the front of this information card.
  - *Record the bar code number that is located on the test kit, the date you returned the test kit for analysis, and the test location on a piece of paper you will retain for your records.*
  - Place the test kit and this completed information card in the return envelope and seal the envelope. For better security, tape the envelope after sealing it.
  - If necessary, place stamps on the envelope and return the test kit immediately to Alpha Energy Laboratories for analysis. You should receive your results within approximately 4 weeks of receipt at the laboratory. This accounts for the mailing time to the lab, analysis time, and the time to mail a report back to you.

**FOR FASTER SERVICE - OVERNIGHT (Fed-Ex, UPS, Express Mail) YOUR TEST KIT TO THE ADDRESS SHOWN ON THE FRONT OF THIS INFORMATION CARD. PROVIDE AN EMAIL OR FAX FOR THE RETURN REPORT.**



# ALPHA ENERGY LABORATORIES

c/o Alpha Energy Labs  
2501 Mayes Rd., Suite 100  
Carrollton, TX 75006  
(800) 324-5928

## LONG-TERM RADON TEST INFORMATION CARD

TEST INSTRUCTIONS ON BACK

PLEASE COMPLETE THIS CARD AND RETURN  
WITH THE RADON SAMPLER AT THE END OF THE TEST.

Consider using PRIORITY MAIL to ensure delivery to Lab within specified time frame.

Company Name:

Last Name:  First:

Street:

City:

State:  Zip:

Tel:  Fax:

Email:

check your results via internet at [www.drhomeair.com](http://www.drhomeair.com)

Reason for test: Real Estate Transaction  Post Mitigation  Personal Knowledge

Serial Number located on plastic tray of kit. Must have this number when contacting lab.

Test Kit Serial No.: **A T**

Test Start: MO  DATE  YEAR

Test Stop: MO  DATE  YEAR

Test Floor: Basement  1st Floor  2nd Floor

Structural Type: Basement  BiLevel  Slab-on-Grade  Crawlspace

Test Location:

(Place where test was conducted ie: specific room or actual address if different from mailing address)

YOUR SIGNATURE: \_\_\_\_\_